

Manual, Assembly instruction: Brodit 854001

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the frame surrounding the air vent and the dashboard, to widen the gap. Peel off the adhesive tape covers on the ProClip.

2. Hook the upper part of the ProClip over the lower edge of the air vent.

3. Prize the gap slightly wider using the gap opener, in the same time press the left side of the angled edge on the lower part of the ProClip into the gap next to the gap opener. Pull out the gap opener and press it into the gap by the console corner, in the same time press forward on the right side of the lower part of the ProClip so the angled edge goes all the way into the gap. Pull out the gap opener. Press upward on the lower edge of the ProClip so it is properly in place.

4. The ProClip is in place.