

Manual, Assembly instruction: Brodit 854005

Angled mount Compare our pictures with your car. Fits only the same style radio as shown.



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap in the center console sidewall, to widen it. Peel off the cover of adhesive tape on the ProClip.

2. Press the angled edge on the left side of the ProClip into the gap between the center console panel frame and the console edge.

3. Press firmly forward on the right side of the ProClip so the angled edge hooks into the gap above the gap opener. Press until you see or hear/feel it snaps into place. Pull out the gap opener.

4. The ProClip is in place.