

Manual, Assembly instruction: Brodit 854007

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the air vent panel frame and the dashboard ledge, to widen it. Peel off the cover of adhesive tape on the ProClip.

2. Hold the ProClip in an almost horizontal position. Press the curved edge on the lower part of the ProClip into the gap between the air vent panel overhang and the stereo. Press until you see or hear/feel it snaps into place. Then flip the ProClip upwards, towards the air vent.

3. Press firmly forward on the upper part of the ProClip so the angled edge goes into the gap next to the gap opener. Press until you see or hear/feel it snaps into place. Pull out the gap opener.

4. The ProClip is in place.