

Manual, Assembly instruction: Brodit 854013

Center mount NOT for models with flip down navigation system.

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the stereo and the air vent panel frame, to widen the gap. Hold the gap opener in the gap with one hand and press the vertical grooved edge on the lower part of the ProClip half way into the gap with your other hand. Pull out the gap opener.

2. Press the gap opener into the gap between the center console panel frame and the dashboard edge. Hold the gap opener in the gap with one hand and press firmly forward on the upper mid part of the ProClip with your other hand, so the grooved edge goes into the gap next to the gap opener. Press until you see or hear/feel it snaps into place. Pull out the gap opener.

3. The ProClip is in place.

4. The ProClip is in place.