

Manual, Assembly instruction: Brodit 854014

Angled mount NOT for models with flip down navigation system.

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the cover of adhesive tape on the ProClip. Hold the ProClip in an almost 45 degree angle of the dashboard and press/hook the curved edge on the right side of the ProClip into the gap between the air vent panel frame and the dashboard front panel. Flip the ProClip towards the dashboard so the curved edge hooks behind the front panel of the dashboard.

2. Press the thin end of the enclosed gap opener into the gap between the stereo and the air vent panel frame, to widen the gap. Hold the gap opener in the gap with one hand and press firmly forward on the left side of the ProClip with your other hand, so the grooved edge goes into the gap below the gap opener. Press until you see or hear/feel it snaps into place. Pull out the gap opener.

3. The ProClip is in place.

4. The ProClip is in place.