

Manual, Assembly instruction: Brodit 854017

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the tray and the dashboard, to widen it. Peel off the cover of adhesive tape on the ProClip. Hook the angled edge on the lower part of the ProClip around the panel frame surrounding the stereo.
2. Press firmly forward on the upper part of the ProClip so the angled edge goes into the gap next to the gap opener. Press until you see or hear/feel it snaps into place.
3. Press firmly down on top of the ProClip to make sure the angled edge is all the way into the gap. Pull out the gap opener.
4. The ProClip is in place.