

Manual, Assembly instruction: Brodit 854020

Center mount ONLY for WT, LT1 and LT2.

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. NOTE: This ProClip ONLY fits for the dashboard style with one air vent on each side of the stereo. This ProClip will NOT work with standard holders - ONLY with holders with tilt swivel. The tilt swivel is needed to extend the holder from the ProClip face plate to clear the bottom part of the holder off the dashboard ledge.

1. Press the thin end of the enclosed gap opener into the gap between the air vent panel frame and the dashboard, to widen it. Press the long back part of the ProClip into the gap next to the gap opener so the grooved edge snaps over the edge underneath the air vent panel frame.

2. Place your fingers behind the ProClip face plate and push forward. At the same time press down in front of the face plate, with your thumbs, so the angled edge goes into the air vent and hooks around the air vent edge. Pull out the gap opener.

3. The ProClip is in place.

3. The ProClip is in place.