

Manual, Assembly instruction: Brodit 854027

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the cover of adhesive tape on the ProClip. Hook the angled edge on the left side of the ProClip around the center console edge.
2. Press firmly forward on the right side of the ProClip so the angled edge goes into the gap in the center console sidewall. Press until you see or hear/feel it snaps into place.
3. The ProClip is in place.
4. The ProClip is in place.