

Manual, Assembly instruction: Brodit 854031

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap openers into the gap between the silver trim and the dashboard, to widen it. Peel off the cover of adhesive tape on the ProClip. Press/hook the angled edge on the upper part of the ProClip into the gap between the gap openers. Press until you see or hear/feel it snaps into place.
2. Pull out the gap openers. Slide the ProClip, while in the gap, over to the left side.
3. Press a opener into the gap between the silver trim and the dashboard. Press firmly forward on the center part of the ProClip so the grooved edge goes into the gap above the gap opener. Press until you see or hear/feel it snaps into place. Pull out the gap opener.
4. The ProClip is in place.