

Manual, Assembly instruction: Brodit 854032

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap openers into the gap between the center console panel frame and the console edge, to widen it. Peel off the cover of adhesive tape on the ProClip.

2. Press the angled edge on the left side of the ProClip into the gap between the gap openers. Pull out the gap openers.

3. Press the gap openers into the gap between the center console side edge and the console sidewall. Press firmly forward on the right side of the ProClip so the angled edge goes into the gap between the gap opener. Press until you see or hear/feel it snaps into place. Pull out the gap openers.

4. The ProClip is in place.