

Manual, Assembly instruction: Brodit 854038

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. This ProClip consists of two parts. Part 1. Attaching part (the smallest part) Part 2. ProClip face plate

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap openers into the gap between the center console panel frame and the dashboard, to widen the gap. Peel off the cover of the adhesive tape on Part 1.

2. Align the top of Part 1 with the panel line above the temperature controls (see white line in the photo). Press the angled edges of Part 1 into the gap, at the same time bend Part 1 to the right until you see or hear/feel it snaps into place. Slide Part 1 downwards until it stops. Press Part 1 towards the console edge so the adhesive tape attaches. Pull out the gap openers.

3. Press a screwdriver (Philips) firmly through the predrilled holes in Part 2 to open them up. Peel off the cover of the adhesive tape on Part 2. Place Part 2 onto Part 1 so the holes match and the adhesive tape is on the left side. Screw Part 2 onto Part 1 using the enclosed screws. Press the ProClip to the right for optimal adjustment and tighten the screws.

4. The ProClip is in place.