

Manual, Assembly instruction: Brodit 854045

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. This ProClip consists of two parts. Part 1. Attaching part (the smallest part) Part 2. ProClip face plate

1. Press the thin end of the enclosed gap openers into the gap between the center console panel frame and the padded part of the dashboard, to widen the gap. Peel off the cover of the adhesive tape on Part 1. Place the angled edge of Part 1 against the gap between the gap openers.

2. Press the angled edge firmly into the gap and at the same time bend Part 1 to the right until you see or hear/feel it snaps into place, and the adhesive tape attaches to the padded dashboard. Press firmly forward on Part 1 to make sure it is all the way into the gap. Pull out the gap openers.

3. Press a screwdriver (Philips) firmly through the predrilled holes in Part 2 to open them up. Peel off the cover of the adhesive tape on Part 2. Place Part 2 onto Part 1 so the holes match and the adhesive tape on Part 2 is on the left side. Do not attach the tape to the center console panel frame yet. Screw Part 2 onto Part 1 using the enclosed screws. Right before you tighten the screws, press the ProClip to the right with your thumb for optimal adjustment of the mount. Hold it in that position and tighten the screws.

4. The ProClip is in place.