

Manual, Assembly instruction: Brodit 854046

Angled mount ONLY for models with upper glove compartment.



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Open the top compartment next to the right air vent. Press the thin end of the enclosed gap opener into the gap between the dashboard ledge and the panel frame below the air vent, to widen it. (See arrow in image). Peel off the cover of adhesive tape on the ProClip. Press the curved edge on the upper part of the ProClip into the gap next to the gap opener. Press until you see or hear/feel it snaps into place.

2. Slide the ProClip all the way to the left. Open the glove compartment.

3. Press firmly forward on the lower part of the ProClip so the angled edge hooks around the dashboard edge by the glove compartment. Close the glove compartment and the top compartment. Pull out the gap opener.

4. The ProClip is in place.