

Manual, Assembly instruction: Brodit 854062

Center mount, High



Please read all of the instructions and look at the pictures before attaching the ProClip. It is very important to install the ProClip in the exact same position as shown in the pictures.

- 1.** Press the thin end of the enclosed gap opener into the gap between the frame surrounding the air vent and the trim, to widen the gap. Peel off the adhesive tape covers on the ProClip.
- 2.** Place the ProClip above the gap between the frame surrounding the air vent and the dashboard, in the same position as shown in the picture. Press the angled edge on the lower part of the ProClip into the gap next to the gap opener.
- 3.** Press the upper part of the ProClip into the gap between the panel surrounding the display and the dashboard overhang. Pull out the gap opener.
- 4.** The ProClip is in place.