

Manual, Assembly instruction: Brodit 854063

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the control panel and the surrounding frame, to widen the gap. Peel off the adhesive tape covers on the ProClip.
2. Press the upper part of the grooved edge on the ProClip into the gap below the gap opener.
3. Press forward on the lower part of the ProClip so the grooved edge goes all the way into the gap. Press until you hear/feel it snaps into place and the adhesive tape attaches to the control panel. Pull out the gap opener.
4. The ProClip is in place.