

Manual, Assembly instruction: Brodit 854065

Center mount, NOT for vehicles with navigation system

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the frame surrounding the control panel and the dashboard, to widen the gap. Peel off the adhesive tape covers on the ProClip.
2. Press the angled edge on the left part of the ProClip into the gap above the gap opener.
3. Hook the angled edge on the right part of the ProClip over the frame surrounding the stereo. Pull out the gap opener.
4. The ProClip is in place.