

Manual, Assembly instruction: Brodit 854067

Center mount, ONLY for vehicles with navigation system

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the adhesive tape covers on the ProClip. Press the angled edge on the left part of the ProClip into the gap between the frame surrounding the air vent and the frame surrounding the control panel.

2. Flip the ProClip forward/rightward so the angled left edge hooks into the gap and the right part hooks over the frame surrounding the control panel.

3. Press the angled edge on the right part of the ProClip into the gap between the display and the surrounding frame.

4. The ProClip is in place.