

Manual, Assembly instruction: Brodit 854072

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the adhesive tape covers on the ProClip. Press the curved edge on the right part of the ProClip into the gap in the center console sidewall.
2. Flip the ProClip leftward, toward the steering wheel, so the curved right edge hooks into the gap. Hook the angled edge on the left part of the ProClip into the gap between the control panel and the surrounding frame.
3. Press forward on the left part of the ProClip so the angled edge goes all the way into the gap.
4. The ProClip is in place.