

Manual, Assembly instruction: Brodit 854074

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the adhesive tape covers on the ProClip. Press the curved edge on the upper part of the ProClip into the gap on top of the dashboard. Flip the ProClip toward you/downward so the curved edge hooks into the gap.
2. Pull the ProClip toward you and hook the angled edge on the lower part under the upper edge of the air vent housing.
3. Press downward on top of the ProClip so the adhesive tape attaches.
4. The ProClip is in place.