

Manual, Assembly instruction: Brodit 854077

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the coin compartment and the dashboard, to widen the gap. Peel off the adhesive tape covers on the ProClip. Hook the angled edge in the lower part of the ProClip under the upper edge of the air vent housing.
2. Pull the ProClip toward you and hook the angled edge on the upper part into the gap next to the gap opener.
3. Press downward on the upper part of the ProClip so the angled edge goes all the way into the gap. Pull out the gap opener.
4. The ProClip is in place.