

Manual, Assembly instruction: Brodit 854082

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Press the thin end of the enclosed gap opener into the seam/gap on top of the dashboard in front of the information window, to widen the gap. Hold the ProClip in an almost 90 degree angle and press the lip of the curved edge into the seam/gap next to the gap opener. Then pull out the gap opener.

2. Flip the ProClip downward, toward the stereo, so the curved edge on the back part of the ProClip hooks underneath the information window panel. Note: When flipping the ProClip towards the stereo press down on the back part of the ProClip with your index finger to keep the curved edge in the gap.

3. Continue to flip the ProClip towards the stereo until the angled edge on the front part of the ProClip is right above the stereo. Press down on top of the front part of the ProClip until the angled edge goes into the gap between the stereo and the surrounding panel frame. Press until you see or hear/feel the angled edge click into place.

4. The ProClip is in place.