

Manual, Assembly instruction: Brodit 854085

Center mount, High

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the adhesive tape cover on the ProClip. Place the angled edge on the right part of the ProClip into the gap between the control panel and the surrounding frame.
2. Press the right part of the ProClip into the gap.
3. Press forward on the left side of the ProClip so the angled edge hooks into the gap in the dashboard.
4. The ProClip is in place.