

Manual, Assembly instruction: Brodit 854091

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the cover of adhesive tape on the ProClip. Place the angled edge on the lower part of the ProClip into the gap/seam between the air vent and the air vent edge.

2. Press down on the upper part of the ProClip and the grooved edge onto the air vent edge. **3** The ProClip is in place.

4. The ProClip is in place.