

Manual, Assembly instruction: Brodit 854092

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the cover of adhesive tape on the ProClip. Place the ProClip over the console edge so the left part hooks over the control panel edge.

2. Press firmly forward on the face plate so the angled edge on the right side of the ProClip snaps into the gap between the console edge trim and the glove compartment frame. If the gap is tight, use the thin end of the enclosed gap opener to widen the gap below the ProClip.

3. Press the gap opener into the gap above the ProClip to widen the gap so the angled edge snaps into place. Pull out the gap opener.

4. The ProClip is in place.