

Manual, Assembly instruction: Brodit 854096

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the air vent panel frame and the center console panel frame, to widen the gap. Peel off the cover of adhesive tape on the ProClip.

2. Press the angled edge on the lower part of the ProClip into the gap next to the gap opener. Pull out the gap opener.

3. Press the gap opener into the gap between the air vent panel frame and the top of the dashboard. Press forward on the upper part of the ProClip, with your thumb or one hand, so the ProClip flexes forward and meets the gap next to the gap opener. Then press firmly down on top of the ProClip, with your finger or other hand, so the angled edge goes into the gap. Press until you see or hear/feel it click into place. Pull out the gap opener.

4. The ProClip is in place.