

Manual, Assembly instruction: Brodit 854101

Center mount NOT for models with navigation screen.



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the cover of adhesive tape on the ProClip. Hook the angled edge on the back part of the ProClip around the panel frame edge surrounding the information window
2. Place your fingers behind the front part of the ProClip. Pull the ProClip towards you and hook the angled edge around the air vent edge.
3. The ProClip mount is in place.
4. The ProClip mount is in place.