

Manual, Assembly instruction: Brodit 854103

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the console edge and console sidewall, to widen it. Peel off the cover of adhesive tape on the ProClip. Hook/press the angled edge on the right side of the ProClip into the gap next to the gap opener. Pull out the gap opener.
2. Press the gap opener into the gap between the stereo and the surrounding panel frame. Place your finger behind the front part of the ProClip and pull it towards you. Then push it to the left and hook the angled edge on the left side of the ProClip into the gap below the gap opener.
3. Press firmly forward on the left side of the ProClip to make sure the angled edge is all the way into the gap. Pull out the gap opener.
4. The ProClip is in place.