

Manual, Assembly instruction: Brodit 854111

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the cover of adhesive tape on the ProClip. Press the thin end of the enclosed gap opener into the gap between the stereo and the surrounding frame, to widen the gap. Press the thin end on the lower part of the ProClip into the gap next to the gap opener.

2. Press firmly forward on the upper part of the ProClip so the angled edge hooks the air vent panel frame.

3. Press the upper part of the ProClip toward the air vent panel frame so the angled upper edge goes all the way into the gap. Pull out the gap opener.

4. The ProClip is in place.