

Manual, Assembly instruction: Brodit 854121

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press an edge of the lower edge of the ProClip into the gap between the frame surrounding the air vent and the dashboard.
2. Press the ProClip downward so all of the lower edge goes into the gap.
3. Press the upper part of the ProClip downward so the grooved edge hooks under the upper part of the air vent. Press until you hear/feel it snaps into place.
4. The ProClip is in place.