

Manual, Assembly instruction: Brodit 854124

Center mount NOT for PopStar.

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the frame surrounding the air vent and the stereo, to widen the gap. Peel off the adhesive tape cover on the ProClip.
2. Press the upper part of the ProClip into the upper edge of the air vent.
3. Press the grooved edge on the lower part of the ProClip into the gap next to the gap opener. Press until you hear/feel it snaps into place. Pull out the gap opener.
4. The ProClip is in place.