

Manual, Assembly instruction: Brodit 854128

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the adhesive tape cover on the ProClip. Open the glove compartment. Pull out the panel between the glove compartment and the control panel a few millimeter. Press the upper part of the ProClip into the gap under the dashboard overhang.

2. Press the lower part of the ProClip into the gap between the trim and the pulled out panel. Slide the ProClip all the way to the left until it stops.

3. Press forward on the ProClip so it is properly in place. Press the panel back into place. Close the glove compartment.

4. The ProClip is in place.