

## Manual, Assembly instruction: Brodit 854132

Center mount

1.)



2.)



3.)



4.)



**Please read all of the instructions and look at the pictures before attaching the ProClip.**

1. Press the thin end of the enclosed gap opener into the gap between the frame surrounding the air vent and the dashboard trim, to widen the gap. Peel off the adhesive tape cover on the ProClip.
2. Press the grooved edge on the upper part of the ProClip into the gap between the dashboard overhang and the trim. Press until you hear/feel it snaps into place.
3. Press the angled edge on the lower part of the ProClip into the gap next to the gap opener. Pull out the gap opener.
4. The ProClip is in place.