

Manual, Assembly instruction: Brodit 854133

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap openers into the gap between the frame surrounding the air vent and the trim, to widen the gap. Peel off the adhesive tape cover on the ProClip.
2. Press the grooved edge on the upper part of the ProClip into the gap between the dashboard overhang and the trim. Press until you hear/feel it snaps into place.
3. Press the angled edge on the lower part of the ProClip into the gap between the gap openers. Pull out the gap openers.
4. The ProClip is in place.