

Manual, Assembly instruction: Brodit 854142

Angled mount ONLY for models with automatic gear shift.

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener firmly into the gap between the dark panel and the surrounding center console panel, to widen the gap. Peel off the cover of adhesive tape on the ProClip.

2. Press the angled edge on the lower left side of the ProClip into the gap and then follow through upwards with the rest of the angled edge. Press until you see or hear/feel it click into place. Pull out the gap opener.

3. Press the gap opener firmly into the gap in the side wall. Press firmly down on the right side of the ProClip (behind the face plate) so the angled edge goes into the gap next to the gap opener. Press until you see or hear/feel it click into place. Pull out the gap opener.

4. The ProClip is in place.