

## Manual, Assembly instruction: Brodit 854146

Angled mount

1.)



2.)



3.)



4.)



**Please read all of the instructions and look at the pictures before attaching the ProClip.**

**1.** Press the thin end of the enclosed gap opener in to the seam between the dashboard edge and the narrow plastic trim. Flip the trim out and remove it. Pull out the gap opener. Loosen the two screws holding the upper wood grain panel in place. Press the gap opener behind the wood grain panel and bend the panel put.

**2.** Peel off the cover of adhesive tape on the ProClip. Hook the angled edge on the upper part of the ProClip over the wood grain edge. Pull out the gap opener. Press firmly forward on the lower part of the ProClip for best possible attachment of the adhesive tape.

**3.** Tighten the screws holding the upper panel. Hook the narrow trim back into place and press forward so the trim clips attach properly.

**4.** The ProClip is in place.