

Manual, Assembly instruction: Brodit 854147

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed straight gap opener into the gap between the air vent panel frame and the stereo, to widen the gap. Peel off the cover of adhesive tape on the ProClip. Press the grooved edge on the lower part of the ProClip into the gap next to the gap opener. Press until you see or hear/feel it click into place.

2. Hook/press the angled thin end of the other enclosed gap opener into the gap between the air vent ledge and the information window.

3. Press firmly down on top of the gap opener to widen the gap further with your right hand. With your left hand press forward on the upper part of the ProClip so it flexes forward. Then press down on top of the ProClip so the angled edge goes into the gap next to the gap opener. Press until you see or hear/feel it click into place. Pull out the gap openers.

4. The ProClip is in place.