

Manual, Assembly instruction: Brodit 854149

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the cover of adhesive tape on the ProClip. Hold the ProClip in a 90 degree position and press the curved edge into the gap between the dashboard top and the dashboard edge.
2. Flip the ProClip downward, towards the air vent, so the curved edge hooks underneath the dashboard top.
3. Push/pull the ProClip downward and hook the angled edge around the dashboard edge.
4. The ProClip is in place.