

Manual, Assembly instruction: Brodit 854155

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the cover of adhesive tape on the ProClip. Press the thin edge on the top of the ProClip into the gap between the upper part of the air vent and the padded top of the dashboard.

2. Press up on the lower part of the ProClip, push it forward and hook it into the gap/seam between the air vent and the silver trim.

3. Press down on the inside of the ProClip to make sure the angled edge is all the way into the gap.

4. The ProClip is in place.