

Manual, Assembly instruction: Brodit 854164

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the dashboard and the top of the center console panel, to widen the gap. Peel off the cover of adhesive tape on the ProClip.
2. Hook the angled edge on the lower part of the ProClip around the upper air vent edge.
3. Place your thumb on the upper front part of the ProClip (behind the face plate) and press firmly forward. The back part of the ProClip will flex towards the gap opener. Then press down on top of the ProClip with your fingers so the curved edge hooks around the edge of the center console panel next to the gap opener. Press until you see or hear/feel it click into place. Pull out the gap opener.
4. The ProClip is in place.