

Manual, Assembly instruction: Brodit 854165

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the frame surrounding the control panel and the dashboard, to widen the gap. Peel off the adhesive tape covers on the ProClip. Place the ProClip between the air vents. Hook the angled edge on the upper part of the ProClip into the air vent by the windscreen.

2. Pull the ProClip toward you and press it downward so the angled edge on the lower part goes into the gap next to the gap opener.

3. Press forward on the lower part of the ProClip so the angled edge goes all the way into the gap and the adhesive tape attaches. Pull out the gap opener.

4. The ProClip is in place.