

Manual, Assembly instruction: Brodit 854169

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the adhesive tape covers on the ProClip. Press the curved edge on the upper part of the ProClip into the gap between the frame surrounding the display and the dashboard, to widen the gap.
2. Flip the ProClip downward so the curved upper edge hooks under the frame surrounding the display.
3. Hook the angled edge on the lower part of the ProClip under the upper edge of the air vent.
4. The ProClip is in place.