

Manual, Assembly instruction: Brodit 854179

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the control panel and the dashboard overhang, to widen the gap. Peel off the adhesive tape covers on the ProClip. Press the curved edge on the lower part of the ProClip into the gap next to the gap opener.
2. Flip the ProClip upward/forward so the curved lower edge hooks behind the control panel. Hook the angled upper edge into the gap between the dashboard and the coin compartment.
3. Press down on top of the ProClip so the angled edge goes all the way into the gap. Pull out the gap opener.
4. The ProClip is in place.