

Manual, Assembly instruction: Brodit 854180

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the adhesive tape cover on the ProClip. Press the angled edge on the lower part of the ProClip into the gap between the frame surrounding the control panel and the dashboard. Press the ProClip forward/upward so the angled edge hooks behind the dashboard.

2. Press the upper part of the ProClip downward and forward and hook the angled edge into the gap between the frame surrounding the coin compartment and the panel frame.

3. The ProClip mount is in place.

4. The ProClip mount is in place.