

## Manual, Assembly instruction: Brodit 854181

Angled mount

1.)



2.)



3.)



4.)



**Please read all of the instructions and look at the pictures before attaching the ProClip.**

1. Press the thin end of one of the enclosed gap openers into the gap in the center console sidewall, to widen the gap. Peel off the adhesive tape cover on the ProClip. Hook the angled edge on the right part of the ProClip into the gap above the gap opener. Slide the ProClip upwards in the gap until it stops. Pull out the gap opener.

2. Press the gap opener into the lower right corner of the gap between the frame surrounding the control panel and the center console. Slide the gap opener upward in the gap so it reaches the upper corner. Press the other gap opener into the lower right corner of the same gap.

3. Keep the gap openers in that position and press them forward so the gap is widened. In the same time: Hook the angled edge of the left part of the ProClip into the gap between the gap openers. Press forward on the left part of the ProClip so the angled edge goes all the way into the gap. Pull out the gap openers.

4. The ProClip is in place.