

Manual, Assembly instruction: Brodit 854184

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Clean the area where the ProClip is to be installed with the enclosed alcohol pad. Press the thin end of the enclosed gap opener into the gap between the control panel and the surrounding frame, to widen the gap. Peel off the adhesive tape covers on the ProClip. Place the ProClip by the center console frame and press the ProClip forward so it hooks on both sides of the frame.
2. Press the ProClip forward so the right side hooks around the center console frame.
3. Press the left side of the ProClip toward the center console frame so the angled edge goes into the gap next to the gap opener. Pull out the gap opener.
4. The ProClip is in place.