

Manual, Assembly instruction: Brodit 854191

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. With your right hand, press the thin end of the enclosed gap openers into the gap between the center console panel frame and the console sidewall, to widen gap. Peel off the cover of adhesive tape on the ProClip.
2. Hook/press the angled edge on the right side of the ProClip into the gap between the gap openers.
3. Place your fingers behind the ProClip face plate and press the ProClip to the left so the angled edge on the left side hooks around the center console edge. Pull out the gap openers.
4. The ProClip is in place.