

Manual, Assembly instruction: Brodit 854193

Center mount NOT for models with factory navigation.

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the dashboard ledge and the information window panel frame, to widen the gap. Peel off the cover of adhesive tape on the ProClip.
2. Press down on top of the back part of the ProClip and push the grooved edge into the gap next to the gap opener. Press until you see or hear/feel it click into place. Pull out the gap opener.
3. Place your fingers behind the front part of the ProClip. Pull the ProClip towards you and hook the angled edge around the air vent edge.
4. The ProClip is in place.