

Manual, Assembly instruction: Brodit 854194

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the cover of adhesive tape on the ProClip. Place the angled edge on the left side of the ProClip over the center console edge.
2. Press firmly forward on the right side of the ProClip. The ProClip will now flex forward so the curved edge hooks around the edge of the center console trim.
3. Press until you see or hear/feel it click into place.
4. The ProClip is in place.