

Manual, Assembly instruction: Brodit 854195

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Place the grooved edge on the lower part of the ProClip onto the lower air vent edge.
2. Press down on the upper part of the ProClip and hook the grooved edge onto the upper air vent edge.
3. Place your thumb underneath the upper part of the ProClip and press upwards to make sure the air vent edge is properly fit into grooved edge on the ProClip.
4. The ProClip is in place.