

Manual, Assembly instruction: Brodit 854203

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the climate control panel and its surrounding panel frame, to widen the gap. Peel off the cover of adhesive tape on the ProClip.

2. Hook the angled edge on the lower part of the ProClip into the gap next to the gap opener. Pull out the gap opener.

3. Press the gap opener into the gap between the center console panel frame and dashboard. Press firmly forward on the upper part of the ProClip so the angled edge goes into the gap next to the gap opener. Press down on top of the ProClip to make sure the angled edge is all the way into the gap. Pull out the gap opener.

4. The ProClip is in place.